

# Review EVERY TIME you use the BCS

**REMEMBER!** There are three big mistakes that damage the BCS:

- Lack of oil or dirty oil
- Old gas or dirty gas
- Running the BCS with the choke on

## SAFETY CHECK:

- Closed toed shoes, no loose fabrics

## BEFORE YOU START THE BCS:

- Check the oil level. ADD OIL if it is not full. DO NOT use the BCS if the oil is low.
- Check the gas.
- Make sure everything is in neutral.
- Adjust the height of the rototiller if you want.

## WHEN STARTING THE BCS:

- Put the throttle on full.
- If a cold start, put the choke on. You do not have to do this if it was started recently.
- If it is cold outside, the machine may need to run at ½ choke for 30 seconds before you turn the choke off.
- After starting, TURN THE CHOKE OFF.

## WHEN USING THE ROTOTILLER:

- ONLY USE THE ROTOTILLER in 1<sup>st</sup> gear, with the throttle at full power.

## AFTER USING THE ROTOTILLER:

- Put everything in neutral again, including the clutch.
- Clean the tines. Rolling the tines backwards can help unwind anything that is caught.