

Wash Station Rules

NEVER leave a hose with water running on the ground.

NEVER pour water out of **ANYTHING** onto the ground where people walk.

This makes it very muddy and dangerous.

Do not change any of the settings or valves on the well. You do not need to adjust anything at the well to use the wash station. Every hose should have water running through it and you can just turn the hose on or off at the end of the hose, NOT at the well. Always leave the well ON, all the valves ON, and the pressure at 60 psi.

Use the on and off valve at the end of the hose to control the water.

Before washing:

- Make sure the tub is sitting in the right place for the water to drain into the pipe.
- Do not move the tables. They need to be very flat for the water to drain the best and they have been set up very carefully to help the water drain.

After washing:

- Make sure the little strainer is sitting in the pipe to catch anything that comes out of the tub. Otherwise the drain pipes will slowly get very stuck.
- *Open the drain plug slowly and by hand.*
 - If you pull on the rope you can break the plug. *Open it by hand.*
 - If you open it too fast the water will not make it down the pipe and will spill and make a mess. *Open it slowly.*
- Throw away the extra leaves and other scraps into the compost pile. Don't just leave them on the ground.